

▶ WOODY W52

♂ Working vest

size [cm]	44 - 46	48 - 50	52 - 54	56 - 58	60 - 62
А	72	74	76	78	80
С	54	58	62	66	71

All size specifications listed are in cm. Accepted tolerance of up to \pm 7–5%.

